



## IAG Performance V3 Street Series AOS PCV Line Kit (12") - Install Instructions

**Part# IAG-RPL-HSE-718X-PCV**

**Fitment:** *EJ25/FA20 DIT Engines*

### Removal of Existing PCV Line:

1. Locate the white check valve in the PCV line leading to the intake manifold.
2. Remove the clamp securing the white check valve on the intake manifold side of the hose.
  - **Note:** Leave the clamp on the hose to the intake manifold, as it will be reused.
3. Carefully pull the intake manifold side of the hose off the white check valve.
4. Remove the clamp securing the PCV line to the AOS.
5. Detach the hose and check valve from the AOS.
6. Discard the old hose and check valve.

### Installation of New PCV Line:

1. Install the new hose onto the AOS breather port.
2. Secure the hose by installing the provided clamp onto the barb fitting.
3. Insert the new PCV valve into the hose that remains attached to the intake manifold.
4. Secure the connection by installing the original clamp onto the new PCV valve.

**Installation is complete.** Ensure all clamps are tight and connections are secure before operating the vehicle.